

This drawing contains proprietary information owned or controlled by RP/Visual Solutions and must not be used or disclosed without prior written authorization

DIMENSIONS ARE IN INCHES
TOLERANCES ARE:
FRACTIONS: XX : ± .03
X/X : ± 1/32
DECIMALS: .XXX : ± .010
ANGLES: X : ± .5
XX : ± .20

APPROVED FOR FABRICATION

SIGNATURE:

DATE:

NOTES:

INSTALLATION INSTRUCTIONS:

- USE (1) 1/4-20 X 3/4" SCREW TO ATTACH CATCH BRACKET TO THE BOTTOM RIGHT SIDE OF THE X-ARM AS SHOWN IN DETAIL B & C.
- USE THE SUPPLIED (1) 1/4-20 X 3/4" HEX HD SCREW TO ATTACH THE LOCK BRACKET TO THE BOTTOM OF ARM IN LOCATION AS SHOW IN DETAIL C & D.
- ROTATE THE LOCK BRACKET UNIT HOLES FOR #6-32 SCREW IN-LINE WITH THE X-ARM. SLIDE THE SUPPLIED (1) #6-32 X 5/8" THRU THE INSIDE WALL AND TIGHTEN THE #6-32 LOCKNUT SNUG ON THE OUTSIDE WALL.
- TO OPEN THE X-ARM, PULL THE CORD TO UNLOCK THE X-ARM.

G			
F			
E			
C			
B			
A			
REV:	DESCRIPTION:	BY:	DATE:
DEALER:			
PROJECT:			
SKU:			
PART NO:			
DESCRIPTION:	LOCK BRACKET SUB-ASSY B6		
SIZE:	B	DATE:	09/16/2024
		DRAWN:	SA
		CHECKED:	XXX
DWG. ID:	RPWM-LOCK-B6-INS.1		
JOB NO:		SCALE:	1:9
		SHEET:	1 OF 1
		REVISION:	

